
Installation Manual



Installation Manual

Parts list			
No.	ITEM	SPECS	QUANTITY
А			1
В			1
С			1
D	•	M4*12	4
E		M6	1
F		M4	1
G		МЗ	1
Н		Hardware not included	
I			